












































Fabric Care Symbols Guide

WASHING		BLEACH		IRONING	
 Machine Wash, Normal	hot water, detergent in the washing machine.	 Bleach When Needed	commercial bleach can be used.	 Iron, Any Temperature, Steam or Dry	iron at any temperature and you can use steam.
 Machine Wash, Cold	water temperature should be no higher than 30C (85F) in the washing machine.	 Non-Chlorine Bleach When Needed	only non-chlorine, color-safe bleach. DO NOT use chlorine.	 Iron, Low	iron using steam or dry. Temperature should not exceed 110C (230F).
 Machine Wash, Warm	water temperature should be no higher than 40C (105F).	 Do Not Bleach	DO NOT even think about bleaching.	 Iron, Medium	iron using steam or dry. Temperature should not exceed 150C (300F).
 Machine Wash, Hot	water temperature should be no higher than 60C (140F).	 Tumble Dry, Normal	can dry on hottest setting.	 Iron, High	iron using steam or dry. Temperature should reach 200C (290F).
 Machine Wash, Hot	water temperature should be no higher than 70C (160F).	 Tumble Dry, Normal, Low Heat	can dry on low heat setting.	 Do Not Steam	DO NOT use steam. Dry ironing is fine.
 Machine Wash, Hot	water temperature should not exceed 95C or 200F.	 Tumble Dry, Normal, Medium Heat	can dry on medium heat setting.	 Do Not Iron	DO NOT iron.
 Machine Wash, Permanent Press	machine washed on permanent press setting. It should provide a cold rinse prior to slower spin.	 Tumble Dry, Normal, High Heat	can dry on high heat.	DRYCLEAN	
 Machine Wash, Gentle or Delicate	can use machine, on delicate setting. This means lower agitation.	 Tumble Dry, Normal, No Heat	only use the no heat or air only setting.	 Dryclean	dryclean only.
 Hand Wash	use gentle detergent, DO NOT put in the machine. Wash in the sink and hang to dry.	 Tumble Dry, Permanent Press	only use the permanent press setting.	 Dryclean, Any Solvent	dryclean only.
 Do Not Wash	dry clean only. DO NOT attempt to hand wash or use a washing machine.	 Tumble Dry, Gentle	only use the gentle setting.	 Dryclean, Petroleum Solvent Only	dryclean with petroleum solvent. Other restrictions may be included.
WRING		 Do Not Tumble Dry	hang to dry. DO NOT use a machine.	 Dryclean, Any Solvent Except Trichloroethylene	dryclean only, but do not use trichloroethylene.
 Do Not Wring	DO NOT wring or you will damage the fabric and the item's shape.	 Do Not Dry	DO NOT use a machine see other symbols to indicate drying method.	 Dryclean, Short Cycle	dryclean only, but do not use petroleum or trichloroethylene. Clean on short cycle.
 © The Bedding Site 2005		 Drip Dry	hang from line, but do not hand shape item.	 Dryclean, Reduced Moisture	dryclean only, but do not use petroleum or trichloroethylene.
		 Line Dry	hang item from a washing line.	 Dryclean, Low Heat	dryclean only, but do not use petroleum or trichloroethylene. Use low heat setting.
		 Dry Flat	lay flat for drying. Usually used for wool and sweaters.	 Dryclean, No Steam	dryclean only, but do not use petroleum or trichloroethylene. DO NOT use steam.
		 Dry In Shade	drip dry or line dry, but the colors may fade. Keep out of direct sunlight.	 Do Not Dryclean	do not dryclean.